

IRH-280 Two Channel Infrared Headphones

IRH-280 Dual Audio Headset for 2.3/2.8 MHz

The over the head unit has a two sensor, omni directional optical lens array. It has easily accessible audio level controls, and a power/channel switch. It is powered by two AAA batteries.



Batteries

When new batteries are needed, remove the battery cover by pushing the tab up and lifting the cover off.



Install AAA batteries with the + (positive) end as indicated above. Re-install battery cover.

Adjustable Headband

Adjust the headband to the size needed for the individual patron by pulling or pushing the ear pieces.



Controls

Use the power switch to turn the unit OFF or to select channel A or B. Adjust the left and right volume controls as desired to achieve a comfortable listening level. The monitor switch will mute the sound while the monitor button is held in. The patron may use the headphones as a receiver by plugging their personal hearing aid or earphones into the jack.



